

INSTRUCTION SHEET

Insectakill 30, 40 & 80 watt models

Please read these instructions carefully and store in a safe place for future reference.

INSECTAKILL

Insectakill is designed to be the most effective range of front of house glue pad insect control units on the market. Three sizes of unit are available, 30W, 40W and 80W.

CONTENTS OF PACKAGE

- 1 x Insectakill insect control unit
- 2 x Screws and wall plugs
- 2 x 15 or 20 or 40W High powered insect attractive UV tubes (fitted)

WARNING - THIS APPLIANCE MUST BE GROUNDED

INSECT CONTROL PRODUCTS

Your Insectakill unit attracts flying insects via new high powered ultra violet tubes and then kills the insects on a high voltage killing grid.

POSITIONING

THIS UNIT IS FOR INDOOR USE ONLY.

Your Insectakill unit should ideally be fixed around seven feet above the ground, preferably in the darkest place within the area to be protected and is supplied with a six feet long power cord with fitted plug. Do not position the unit close to windows, skylights or other sources of light or where it may be obscured by furniture, doors or other obstacles. Ideally, your Insectakill unit should be visible from every part of the area to be protected.

INSTALLATION

PRIOR TO INSTALLATION, ENSURE THE VOLTAGE OF YOUR MAINS OUTLET CORRESPONDS TO THAT MARKED ON THE SPECIFICATION LABEL FOUND ON THE BACK OF YOUR UNIT.

Your Insectakill unit should be fixed to the wall with the supplied wall plugs and screws. The unit has a plug fitted to the mains lead and once installed in position, should be plugged into the nearest mains outlet.

USING YOUR INSECTAKILL

Your Insectakill unit should ideally be in operation for 24 hours a day, ensuring your premises are kept free of flying insects. Insects are most attracted to your Insectakill unit at night when there is no competition from daylight or other light sources.

CONTROL ZONE PRODUCTS

INSTRUCTION SHEET

CLEANING

ENSURE THAT THE FLYING INSECT KILLER IS DISCONNECTED FROM THE MAINS BEFORE CLEANING

It is recommended that cleaning is carried out regularly when the catchment tray is emptied. Once the glue pad is removed, the unit should be thoroughly wiped down with a damp cloth, removing any build up of dirt. Ensure the unit is completely dry before reconnecting it to the power supply.

WARRANTY

This quality flying insect control product has a three year warranty (excluding tubes) and if regularly maintained as described in these instructions, will continue to work for many years.

In the unlikely event of the unit not functioning, please contact the distributor you purchased the unit from or email us directly at info@controlzoneproducts.com

TUBE REPLACEMENT

BEFORE REPLACING THE TUBE, ALWAYS ENSURE THAT THE UNIT IS DISCONNECTED FROM THE MAINS SUPPLY.

To ensure the optimum effectiveness of your Insectkill unit, the UV tubes should be replaced every 9 - 12 months. Always ensure replacement tubes are compatible with your unit, available from your PCO or Control Zone Products Inc.

To replace the UV tubes.

1. Rotate the tube through 90 degrees.
2. Gently pull the tube away from the unit.
3. Reverse the process with the replacement tube.

STARTER REPLACEMENT

BEFORE REPLACING THE STARTER, ALWAYS ENSURE THAT THE UNIT IS DISCONNECTED FROM THE MAINS SUPPLY.

The starters should be replaced at the same time as tubes, namely every 9 - 12 months. Always ensure replacement starters are compatible with your unit, available from your supplier or Control Zone Products Inc.

To replace the starters:

1. Release the used starter by turning anti-clockwise and pulling free.
2. Insert the new starter and turn clockwise until locked in position.

CONTROL ZONE PRODUCTS